



BWB-1 SERVICE AND REPAIR MANUAL

BWB-1 Service and Repair Manual.



Contents.

Section.

- 1 Introduction.
- 2 Health and safety.
- 3 Interconnect diagram.
- 4 Fault guide.
- 5 Parts access and removal drawings.
 - 5.1 Removal Sequence.
 - 5.2 Fuses.
 - 5.3 Ignitor.
 - 5.4 Lid and Front Panel.
 - 5.5 Main Cover.
 - 5.6 Main Board.
 - 5.7 LCD.
 - 5.8 12V and 15V PSUs
 - 5.9 Ignition Module.
 - 5.10 Int / Ext Air Switch.
 - 5.11 OTA Assembly
 - 5.12 Pump Assembly.
 - 5.13 Inverter.
 - 5.14 Solenoid and Fan.
 - 5.15 Nebuliser and Mixing Chamber.
 - 5.16 Gas and Air Lines.
 - 5.17 Main Board Test Points.
- 6 Maintenance schedule.
- 7 Spares guide.

1. Introduction.

Intended Use

This Repair and Service Manual contains instructions for the repair and maintenance of the Model BWB-1. This service information for use by **qualified personnel only!**

The Model BWB-1 is intended for use by persons knowledgeable in safe laboratory practices. If the instrument is not used in accordance with these instructions, the protection provided by the equipment may be impaired.

The information contained in this document was correct at the time of publishing. However, BWB Technologies UK, Ltd reserves the right to change specifications, equipment, and procedures at any time, without notice. To obtain a current version go to *www.bwbtechnologies.com.*

Machine Introduction

Introduction

The BWB-1 Performance Plus is a multi-channel, low temperature Flame Photometer for the simultaneous measurement of Na, K, Li, Ca, and Ba in a variety of samples. It is designed for ease of use and reliable, trouble-free operation. With built-in air compressor, diagnostic indications, computer interface and control, automatic gas shut off, choice of Single Point or Multi-Point calibration and internal data handling the BWB-1 provides a simple, yet fully capable, instrument for the modern laboratory.

Summary of the Instrument

The BWB-1 employs a low temperature flame using air and propane, butane, or a combination of the two (as in LPG). Interference type filters are provided for Na, K, Li, Ca, and Ba. All these ions are monitored continuously and results shown on the digital display.

There are dual computer access points provided (RS232 and USB) that allow for interfacing to external software.

Diagnostic indications of several parameters are displayed on the front panel. Safety cut off of the gas supply is provided through constant monitoring of the flame. If the flame should go out for any reason, the gas will automatically stop flowing with a correspondent light on the panel and an audible signal alerting the user.

Embedded in the instrument enclosure is a built-in air compressor. A unique electronic control system automatically regulates the air pressure/flow to the optimum levels. No user adjustments are possible, or necessary, to achieve maximum performance. Provision for an external source of compressed air is included.

2. Health and Safety.

Warning!

The BWB-1 has parts of it that are connected to **High Voltages** that could cause serious injury if touched while the machine is connected to the Mains Supply! Please disconnect the machine from the supply and examine the Parts Removal drawings carefully before attempting to remove or replace any parts of this machine.

This machine has parts that carry pressurised Butane/Propane or LPG that can result in a **Fire Hazard** if the machine is incorrectly Repaired or Serviced. Please make sure the Gas supply is disconnected and the machine has been well ventilated by running the compressor on its own for several minutes.


The chimney assembly of the BWB-1 will get extremely **HOT** during use. Please wait until the unit has cooled down before carrying out any service or repair work.

The LCD, Mainboard, OTA board and the RS232/USB board contain **Electrostatic Sensitive Devices** and suitable precautions should be taken when handling them.

The Nebuliser, Mixing Chamber and Burner assembly may have been exposed or contain chemical residue from Customer use. Suitable safety wear should be employed when handling these parts.

Any Maintenance or Repair to this machine must be carried out by a suitably Qualified or Trained person.


All removed parts should be disposed of in the correct manner or returned to BWB UK for disposal or recycling.






**BWB-1 SERVICE AND REPAIR.
SECTION 4.
FAULT GUIDE.**

BWB-1 Fault and Repair Guide







Page 2




Flame ON?




Page 4






FACTORY OPTIONS.






**BWB-1 SERVICE AND REPAIR.
SECTION 5.
PARTS REMOVAL DIAGRAMS.**



REV	DESCRIPTION	DATE	APPROVED


Step	Instruction
1	Undo Fuse Holders
2	Remove Fuses from Holders
3	Fit new Fuses
4	Replace Fuse Holders



FUSE HOLDER


FUSE HOLDER

NAME	DATE	BWB-1	
DRAWN JNG	09/18/08		
CHECKED			
ENG APPR			
MGR APPR			
TITLE		BWB Fuse removal	
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS ANGLES °XX'		SIZE DWG NO A2	REV 10
2 PL #XXX 3 PL #XXXX		FILE NAME BWBservicefuses.dft	WEIGHT
		SCALE	SHEET 1 OF 1




Chimney Rear View.

Step	Instruction
1	Remove the 6x M4 Screws(A) from the Rear Panel(G)
2	Pull back the Rubber Boot (F) and undo the screw from the Electrode of the Ignitor(C)
3	Remove the 2x M3 Screws(B) from the Inner Chimney(H)
4	Lift out the Inner Chimney(H)
5	Undo the Ignitor Nut(D) and remove the Ignitor(C).



NAME	DATE	BWB-1	
DRAWN	JNG	09/23/08	
CHECKED			
ENG APPR			
MGR APPR			
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS ANGLES °XX°		Ignitor Removal	
SIZE	DWG NO	REV	
A2	BW65M0013	10	
FILE NAME	BW6service/ignitor.dft	SCALE	WEIGHT
2 PL #XXX 3 PL #XXX			



LID


Top View Of BWB-1

Front Panel

Step	Instruction
1	Remove the screws (A) from the Lid
2	Remove the screws (B) from the front panel
3	Lower the front panel to gain access to the internals

NAME	DATE	BWB-1	
DRAWN	09/11/08		
CHECKED			
ENG APPR			
MGR APPR		TITLE	
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS ANGLES °XX'		SIZE	REV
2 PL #XXX 3 PL #XXX		AZ	10
		FILE NAME	BWBServiceLid.dft
		SCALE	WEIGHT
			SHEET 1 OF 1

REVISION HISTORY		
REV	DESCRIPTION	DATE




Step	Instruction
1	Remove the 4 M4 Screws from the Cover
2	Lift the Cover off the Front Panel

NAME	DATE	BWB-1
DRAWN JNG	09/16/08	
CHECKED		
ENG APPR		
MGR APPR		TITLE
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS ANGLES °XX'		SIZE DWG NO
2 PL #XXX 3 PL #XXX		REV
FILE NAME BWBServiceMainCover.dwg	SCALE	REV 10
	WEIGHT	SHEET 1 OF 1

Front Panel (Rear View)

REVISION HISTORY		
REV	DESCRIPTION	DATE

Step	Instruction
1	Remove the cables from the Main PCB
2	Remove the 4 M4x40 Pillars from the Main PCB
3	Remove the Main PCB from the Front Panel



M4 x 40 Pillar (x4)

NAME		DATE		TITLE	
DRAWN	JNG	09/16/08		Main PCB	
CHECKED					
ENG APPR					
MGR APPR					
UNLESS OTHERWISE SPECIFIED		SIZE	DWG NO	REV	
DIMENSIONS ARE IN MILLIMETERS		A2	BWBSM0002	10	
ANGLES °XX°		FILE NAME	BWBSserviceMainPCB.dft		
2 PL #XXX 3 PL #XXXX		SCALE			
		WEIGHT			

BWB-1

Main Board Connectors


REVISION HISTORY

DESCRIPTION

REV

DATE

APPROVED



NAME	DATE
DRAWN JMG	09/16/08
CHECKED	
ENG APPR	
MGR APPR	








TITLE	SIZE	DWG NO	REV
BWB-1	A2	BWBSM0002	10

UNLESS OTHERWISE SPECIFIED
DIMENSIONS ARE IN MILLIMETERS
ANGLES °XX°
2 PL #XXX 3 PL #XXXX



FILE NAME: BWBServiceMainPCB.dft

SCALE: SHEET 2 OF 3

REVISION HISTORY		
REV	DESCRIPTION	DATE




Main Board Connections and Voltages.



NAME		DATE		TITLE	
DRAWN	JNG	09/16/08		Main PCB	
CHECKED					
ENG APPR					
MGR APPR					
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS ANGLES °XXX				SIZE	REV
2 PL #XXX 3 PL #XXX				A2	10
FILE NAME: BWBServiceMainPCB.dwg				SCALE:	WEIGHT:

BWB-1

Spare Pin on LCD Cable to this End!!



M2.5 Nut and Washer (x4)

REVISION HISTORY		
REV	DESCRIPTION	DATE


Step	Instruction
1	Remove the LCD Cable from the LCD.
2	Remove the 4 M2.5 Nuts and washers from the LCD.
3	Remove the LCD from the Front Panel.

NAME	DATE	BWB-1	
DRAWN JNG	09/16/08		
CHECKED			
ENG APPR			
MGR APPR			
TITLE		LCD Removal	
SIZE	DWG NO	REV	
A2	BWBSM0004	10	
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS ANGLES °XX		FILE NAME BWBServiceLCDoff	
2 PL #XXX 3 PL #XXX		SCALE	WEIGHT
			SHEET 1 OF 1

REVISION HISTORY

REV	DESCRIPTION	DATE	APPROVED

Step	Instruction
1	Remove the cables from the PSU
2	Remove the 4 M3x6 Screws from the PSU
3	Remove the PSU From the Main Cover





NAME	DATE	TITLE
DRAWN JING	09/16/08	PSU
CHECKED		
ENG APPR		
MR APPR		
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS ANGLES °XX"		SIZE DWG NO
2 PL #XXX 3 PL #XXX		AZ BWRSM0005
		REV 10
		FILE NAME BWRServicePSU.dft
		SCALE
		WEIGHT
		SHEET 1 OF 2

HIGH VOLTAGE!

110/230VAC


110/230VAC




To PSU Earth Point

12V PSU Connections and Voltages

+12V DC Output





0V DC Output



HIGH VOLTAGE!

110/230VAC

110/230VAC



To PSU Earth Point


15V PSU Connections and Voltages

+5V DC Output

0V DC Output

-15V DC Output

+15V DC Output



REVISION HISTORY		DATE	APPROVED
REV	DESCRIPTION		


DRAWN	JNG	09/16/08	TITLE	PSU
CHECKED				
ENG APPR				
MGR APPR				
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS ANGLES °XX"			SIZE	REV
2 PL #XXX 3 PL #XXX			A2	10
			FILE NAME	BWBServicePSUoff
			SCALE	WEIGHT

BWB-1


Ignition Module removal.

Top View Of Flame Photometer

PLUG to
MAIN BOARD




SOCKET to
IGNITION MODULE



HIGH VOLTAGE!!

IGNITION MODULE



HT LEAD

IGNITION MODULE

Step	Operation
1	Remove two screws holding the Ignition Module to the Case
2	Move the Ignition Module away from the Case
3	Remove the HT Lead from the Ignition Module
4	Separate the Ignition module away from the Ignition Cable
5	Remove the Ignition Module from the Case

NAME	DATE	TITLE
JNG	09/19/08	
CHECKED		
ENG APPR		
MGR APPR		

REV	DESCRIPTION	DATE	APPROVED

SIZE	DWG NO	REV
A2	BWBservice0011	10

FILE NAME	SCALE	WEIGHT	SHEET
BWBservice\ignition.dwg			1 OF 1

UNLESS OTHERWISE SPECIFIED	OTA Removal
DIMENSIONS ARE IN MILLIMETERS	
ANGLES 3XX°	
2 PL .5XXX 3 PL .5XXX	

NAME	DATE	TITLE
JNG	09/19/08	
CHECKED		
ENG APPR		
MGR APPR		


SIZE	DWG NO	REV
A2	BWBservice0011	10

FILE NAME	SCALE	WEIGHT	SHEET
BWBservice\ignition.dwg			1 OF 1

UNLESS OTHERWISE SPECIFIED	OTA Removal
DIMENSIONS ARE IN MILLIMETERS	
ANGLES 3XX°	
2 PL .5XXX 3 PL .5XXX	

REVISION HISTORY			
REV	DESCRIPTION	DATE	APPROVED


SWITCH



Case Top

+12V from Main Board.

SWITCH (REAR VIEW)



0V From Main Board.


The +12V Into the Inverter is marked by Red heatshrink or a "P" Cable marker.

NAME	DATE	BWB-1	
DRAWN	Jason Gartin/06/18/08		
CHECKED			
ENG APPR			
MGR APPR			
TITLE		Air Switch	
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS		SIZE DWG NO	REV
ANGLES °XX°		AZ	BWB00010
2 PL #XXX 3 PL #XXX		SCALE	10
FILE NAME BWBserviceairSW.dft		SHEET 1 OF 1	


OTA Assembly removal.

Step	Action
1	Remove the rear screw from holding the OTA to the Case.
2	Remove the Nyloc and washer from the retaining stud.
3	Remove the two screws holding the OTA Shield in place.
4	Remove the OTA Shield.
5	Unplug the OTA Cable
6	Remove the OTA Assembly from the case.

REV	DESCRIPTION	DATE	APPROVED




Top View Of Flame Photometer



NAME	DATE	BWB-1	
DRAWN JNG	09/18/08		
CHECKED			
ENG APPR			
MGR APPR			
TITLE		OTA Removal	
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS ANGLES XXX°		SIZE DWG NO	REV
2 PL .5XXX3 PL.XXX		A2	BWBservice0012
		FILE NAME: BWBserviceOTA.dft	1.0
		SCALE:	WEIGHT: SHEET 1 OF 1

REVISION HISTORY		
REV	DESCRIPTION	DATE

Pump Connector




HIGH VOLTAGE!!


From	Wire Colour	Alt Colour	Pin	To
Pump	Green/Yellow	Green	GR	Y5141 3 Pin
	Brown	Black	X	US
	Blue	White	W	Connector

Step	Operation
1	Loosen the Clamping Nyloc
2	Slide the Pump Bracket forwards.
3	Remove the Pump Connector from the Inverter
4	Remove the Airline from the AirBarb
5	Remove the 4 screws from the Pump Mounting Points
6	Remove the Pump from the Pump Bracket

Pump Bracket



Clamping Nyloc



NAME	DATE	TITLE
DRAWN JMG	09/2008	BWB Pump Assy
CHECKED		
ENG APPR		
MGR APPR		

UNLESS OTHERWISE SPECIFIED	SIZE	DWG NO	REV
DIMENSIONS ARE IN MILLIMETERS	A2	BWBSM0006	10
ANGLES °XX'			
2 PL. #XXX 3 PL. #XXX			


BWB-1

Mounting Hole


SHEET 1 OF 1

REVISION HISTORY		
REV	DESCRIPTION	DATE

Pump Mounting




Inverter



Fit Pump Mounting to second slot on the inverter

Earth Point




Operation

Step	Operation
1	Remove the Pump Mounting from the Inverter.
2	Remove the earth lead from the Inverter Earth Point.
3	Remove the 4 screws from the Inverter (A)
4	Undo the Blue crimps from the Air Switch.
5	Remove the Inverter from the Main Case.



NAME		DATE		TITLE	
DRAWN	JNG	09/19/08		Inverter Removal	
CHECKED					
ENG APPR					
MGR APPR					
UNLESS OTHERWISE SPECIFIED		SIZE	DWG NO	REV	
DIMENSIONS ARE IN MILLIMETERS		A2	BWBserviceInverter	10	
ANGLES °XX'		FILE NAME: BWBserviceInverter.dwg		SCALE:	SHEET 1 OF 1
2 PL #XXX 3 PL #XXX		WEIGHT:			

BWB-1



REVISION HISTORY		
REV	DESCRIPTION	DATE


Internal View of Solenoid Connector



Step

Instruction

Step	Instruction
	Fan Removal
1	Remove Screws (D) and Nylocs (E) from the Fan(G).
2	Separate the Fan Connector and remove the Fan from the Case.
	Solenoid Removal
3	Remove Screws (A) and Washers (B+C)
4	Disconnect the Solenoid (H) from the Gas Regulator.
5	Disconnect the Internal Gas Line.
6	Remove the Solenoid Connector from the Solenoid.



BWB-1

NAME	DATE
DRAWN JMG	09/23/08
CHECKED	
ENG APPR	
MGR APPR	

TITLE

Fan and Solenoid Removal

UNLESS OTHERWISE SPECIFIED

DIMENSIONS ARE IN MILLIMETERS

ANGLES °XX'

2 PL #XXX 3 PL #XXX

SIZE DWG NO

AZ

BWBSM008

REV 10

FILE NAME BWBServiceFanSolenoid.dft

SCALE:

WEIGHT:

SHEET 1 OF 1




FRONT VIEW
OF CHIMNEY



Instruction

Nebuliser Removal.


- 1 Remove the Gas Tube from Port (D)
- 2 Remove the Air Tube from Port (E)
- 3 Undo the Nebuliser Clamp Screw (C) and remove the Nebuliser Mixing Chamber Removal.
- 4 Remove the Waste Tube from Port (F)
- 5 Disconnect the Mixing Chamber (B) from the Burner Mounting Ring (A) by pulling down the retaining tabs and twisting the Mixing Chamber gently.



NAME	DATE	BWB-1	
DRAWN JMG	09/23/08		
CHECKED		TITLE	
ENG APPR		Nebuliser removal	
MGR APPR		SIZE DWG NO	REV
		A2	BWBS00015 10
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS ANGLES °XX'		FILE NAME	BWBSserviceNebuliser.dft
2 PL #XXX 3 PL #XXX		SCALE	WEIGHT
		SHEET 1 OF 1	

REVISION HISTORY		DATE	APPROVED
REV	DESCRIPTION		

Step	Action
Gas Line Removal	
1	Disconnect the Gas line into the machine.
2	Make a note of how the Gas line runs in the machine!
3	Disconnect the internal Gas line from the Solenoid.
4	Disconnect the Gas from the Nebuliser.
5	Unscrew the Adjustment Knob from the Gas Valve.
6	Undo the Nut holding the Gas Valve in place.
7	Unclip the Gas Filter from the clip on the inside of the case.
8	Remove the Gas line from the Machine.
Air Line Removal	
9	Make a note of how the Air line runs in the machine!
10	Disconnect the Air line from the External Air Barb.
11	Disconnect the Air line from the Pump.
12	Disconnect the Air line from the Nebuliser.
13	Unclip the Air Filter from the clip on the inside of the case..
14	Remove the OTA Assembly from the case.
When Refitting the Gas or Air lines care should be taken to ensure that there are no kinks in the Tubing.	




AIR AND GAS FLOW DIAGRAM

NAME	DATE	BWB-1	
DRAWN	JNG	70/14/08	
CHECKED			
ENG APPR			
MGR APPR			
TITLE		Air and Gas	
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS ANGLES °XX		SIZE	DWG NO
		A2	BWBSM0014
		REV	10
		FILE NAME	BWBServeInflGasDft
		SCALE	WEIGHT
		SHEET 1 OF 1	

REVISION HISTORY		
REV	DESCRIPTION	DATE

Main Board Test Points

Key	Description
A	Conn 40
B	Conn 31
C	TP33 +5V DC
D	TP35 OTA Temp
E	TP36 Flame Detect
F	TP43 Digital Ground
G	TP40 +15V DC
H	TP32 -12V DC OTA
I	TP31 +12V DC OTA
J	TP41 0V DC Gas
K	TP34 U-Tube
L	TP39 +24V DC Gas
M	TP42 +5V DC
N	TP38 +9V DC
O	TP37 +12V DC



NAME		DATE	
DRAWN	JNG	10/14/08	
CHECKED			
ENG APPR			
MGR APPR			
TITLE			
BWB-1 Main Board Test Points			
UNLESS OTHERWISE SPECIFIED		SIZE	REV
DIMENSIONS ARE IN MILLIMETERS		AZ	10
ANGLES °XX'		FILE NAME	BWBMainBoardTP.dft
2 PL #XXX 3 PL #XXX		SCALE	WEIGHT
		SHEET 1 OF 1	



**BWB-1 SERVICE AND REPAIR.
SECTION 6.
MAINTENANCE GUIDE.**

6. Maintenance

6.1 General

To ensure optimum performance, periodic maintenance should be carried out according to this section. Maintenance consists of cleaning on a regular basis and occasional replacement of certain parts. There are no maintenance items inside the main enclosure. It is not recommended that the user enter the main enclosure unless servicing is called for.

NOTE: *Figures 6.7 to 6.14 show the two variations of the Burner, Nebuliser and Mixing chambers.*

6.2 Maintenance Menu

The Maintenance Menu is under the Welcome Menu. To reach the Maintenance Menu, scroll to it and press the “Accept” button. The Maintenance Menu has three options.

- Run Compressor
- Show Info
- Reset Memory+Cal

To choose either option, scroll to it and press “Accept”. To exit, press “Back”.

Air Compressor Only

This is used when performing the Nebuliser Test (see Section 6.6). When activated, the air compressor will start but the instrument will not enter the Start Up routine.

Show Info

The BWB-1 has a timer that records the actual time (in hours) the instrument has been in use. It can be used as a reminder of when to perform maintenance.

Reset Memory+Cal

This resets all the stored calibration data.

6.3 Maintenance Schedule

The following are recommended intervals. Depending on the application they may be extended or shortened as needed.

Daily or 8 hours:

- Empty waste container, if used.
- Check “U” tube is filled with **tap** water.
- Clean Aspiration Needle and Aspiration Tubing.
- Clean any spills in tray.

Weekly or 40 hours:

- Carry out daily maintenance procedure.
- Check the operation of the Nebuliser (see Section 6.6).
- Check the Drain Cup, Mixing Chamber, Burner, “U” tube, Nebuliser, and waste tube. Clean as needed.
- For operations involving protein-containing samples, clean the Mixing Chamber, Aspiration Needle, and Aspiration tubing using a good quality de-proteinizing solution.

Monthly or 200 hours:

- Carry out weekly maintenance procedures.
- Check the air and fuel gas tubing and connections for leaks, using a soap solution. Also, check tubing for stress cracking. Replace as needed.

Semi-annually or 1000 hours:

- Carry out the monthly maintenance procedures.
- Clean the Mixing Chamber, Burner, Nebuliser, and Drain Cup.
- Remove the Inner Chimney. Clean the Inner and Outer Chimneys, as needed, and clean the Chimney Windows.
- Clean the Optical Train Assembly Window.
- Replace “U” tube and waste tubing.

Annually or 2000 hours:

- Carry out the semi-annual maintenance procedure.
- Inspect and replace, as needed, gas tubing, air tubing, and Spark Igniter. See appropriate parts of this Service Manual.

6.4 “U” Tube

The “U” tube must be as supplied and remain free of obstructions or “pinching” that might inhibit waste flow out of the Mixing Chamber. For the start sequence to ignite the flame, the “U” tube must be filled to overflowing with **tap** water (or deionised water with a little salt added to increase conductivity).

To clean, use a detergent solution with subsequent thorough rinsing with tap water. **Do not use organic solvents.** They may swell the tubing material rendering it useless.

6.5 Aspiration Needle and Aspiration Tubing

The heart of Nebuliser function, the Aspiration Needle should be cleaned whenever the functionality of the instrument is in question. Cleaning every so often throughout the day usually keeps blockage to a minimum and is best done by aspirating diluent solution for a few minutes. More severe cleaning can be had by running Cleanout Wire through the inside of the needle and/or long term soaking in a detergent solution.

6.6 Nebuliser

The Nebuliser needs periodic testing for functionality and cleaning.

Testing:

1. Ensure the Needle and Aspiration Tube used for the test are clean and free of obstructions.
2. Unscrew the Nebuliser Retaining Clip and remove the Nebuliser from the Mixing Chamber.
3. Turn on the power to the instrument.
4. From the Welcome Menu, choose Maintenance Menu.
5. From the Maintenance Menu, choose Air Compressor Only to start the air compressor.
6. Aspirate deionised water.
7. Measure the aspiration rate by timing how long it takes to aspirate a known amount of water. The aspiration rate should lie within 1-4 millilitres/minute.
8. Observe the mist. It should consist of fine droplets extending about 15-20 cm. Larger droplets will also be emitted. This is normal.
9. If the aspiration rate is too low or there is no fine mist, the Nebuliser needs cleaning.

Note: *If alternate air supply is being used, there is no need to do steps 3,4,and 5 above. Just turn on the alternate air.*

Cleaning:

1. Unscrew the Nebuliser Retaining Clip and remove the Nebuliser from the Mixing Chamber.
2. Remove the air supply tube, gas supply tube and aspiration tube.
3. Use Cleanout Wire to remove any obstructing materials from the centre hole and small side hole. *Be very careful to not abrade the surfaces of either hole!*
4. Soak all the Nebuliser pieces in a good detergent solution.
5. When fully clean, rinse all the Nebuliser pieces very, very well with deionised water. Allow to dry.
6. Assemble the Nebuliser.
7. Test the cleaned Nebuliser as above.

6.7 Drain Cup

The Drain Cup has a sensor that the software monitors during the Start Up cycle to ensure that the “U” tube is filled with water. For the sensor to operate, the water must have some conductivity. Normal tap water will provide the correct level of conductivity. Always be sure that the inner tube is filled to overflowing. See Figure 6.1. The only maintenance needed is occasional cleaning.




Figure 6.1

Cleaning:

- **Unplug the power cord.**
- Remove Drain Cup from the holding clips.
- Remove “U” tube and waste tube.
- Disconnect Sensor connector at the Drain Cup.
- Clean with a detergent solution, mild acid, or Decon 90. **Do Not use Alcohol as it may damage the Drain Cup.** Rinse thoroughly with water. *Avoid getting any solutions on the lead or connector! If the lead or connector gets wet, allow to completely dry.*
- When dry, reattach the sensor connector.
- Reattach the “U” tube and waste tube. Fit back onto the holding clips. *Be sure that the top rim of the Drain Cup sets on the top clip so that the inner overflow tube is even with the drain opening of the Mixing Chamber.* See Figure 6.1.

6.8 Mixing Chamber

The only maintenance the Mixing Chamber assembly needs is occasional cleaning and O-ring replacement.

Warning: The Mixing Chamber/Burner must be completely cool before proceeding further!

Cleaning:

- Remove Nebuliser from Mixing Chamber (see Section 6.6).
- Remove “U” tube from Mixing Chamber.
- Gently spread the Release Tabs just enough to clear the groove they are in and pull the Mixing Chamber down. See Figure 6.2.
- Separate the Mixing Chamber halves by undoing the two screws that hold them together.
- Clean all parts with a detergent solution, de-proteinizing solution, and/or Decon 90. **Do Not use organic solvents or Alcohol - they will damage the Mixing Chamber body!** Rinse all parts well with deionised water.
- Inspect, and replace if necessary, the O-ring between the two halves.
- Reassemble in the reverse order. Be careful to not damage the Release Tabs.




Figure 6.2




Figure 6.3

6.9 Burner

The only maintenance needed on the Burner is occasional cleaning.

Warning: The Mixing Chamber/Burner must be completely cool before proceeding further!

Cleaning:

- Remove the Chimney Back Piece and the Inner Chimney (see Section 6.10).
- Undo the set screw on the Chimney Mount (see Figure 6.3) and lift the Burner Tube up and out.
- Clean with a detergent solution, Decon 90, or mild acid. Rinse thoroughly with deionised water.
- If needed, the Flame Spreader may be removed via the set screw on the side.
- Reassemble in the reverse order.

6.10 Chimney

The only maintenance needed on the Chimney is occasional cleaning.

Warning: The Chimney assembly must be completely cool before proceeding further!

Cleaning:

- **Unplug the power cord.**
- Remove the Chimney Back Piece.
- Slide back the boot and disconnect the lead to the Spark Igniter.
- Remove the two screws holding the Inner Chimney to the Top Piece. See Figure 6.4.
- Lift the Inner Chimney assembly up and away from the Outer Chimney. *Be very careful to not damage the Spark Igniter.*
- If needed, remove the Spark Igniter from the Inner Chimney.
- Remove the Chimney Windows from the Inner Chimney by undoing the screws on the Window Holders. See Figure 6.5.
- Clean the metal and glass parts of the Inner Chimney with gentle scrubbing using a detergent solution. *Do Not scratch the glass windows nor scrub off the paint on the Chimney pieces.*
- If needed, the Outer Chimney Top Piece/Heat Shield assembly can be removed. Gentle scrubbing with a detergent solution can clean both this assembly and the Outer Chimney Body.
- Reassemble in reverse order.




Figure 6.4




Figure 6.5

6.11 Optical Train Assembly

The only maintenance that can be done with the Optical Train Assembly is to clean the window.

Warning: The Chimney assembly must be completely cool before proceeding further!

Cleaning:

- **Unplug the power cord.**
- Remove the Chimney Back Piece.
- Reach into the Outer Chimney and clean the window *very* gently using a *very* soft cloth or cotton swab soaked in Decon 90. See Figure 6.6.
- Reassemble the Chimney Back Piece.




Figure 6.6

6.12 Replacing the Fuse

Before replacing the fuse unplug the power cord! The fuse is located on the rear panel as part of the Power Input module. Using a small flat screwdriver turn the cap to the left. *Always use the correct fuse.*




Figure 6.7 MK2 Mixing Chamber and Nebuliser.




Figure 6.8 MK1 Mixing Chamber and Nebuliser.



Figure 6.9
MK1 Mixing Chamber and Burner Assembly




Figure 6.10
MK2 Mixing Chamber and Burner Assembly




Figure 6.11
MK1 Nebuliser.




Figure 6.12
MK2 Nebuliser.




Figure 6.13
MK 2 Mixing chamber in position.



Figure 6.14
MK1 Mixing Chamber, Nebuliser and Burner assembly exploded diagram.